

WEEKLY PROGRAMMABLE ELECTRONIC TIMER

- Advanced pre-setting one week before.
- Eight programmable ON/OFF settings.
- To-the-minute setting accuracy.
- Manual override: ON-AUTO-OFF.
- Any one set of time can be changed by using Reset/recall
- LCD displays real time to Day/Hour/Minute/Second and ON/AUTO/OFF.
- Precise and stable timing control by using crystal oscillator.

■ SPECIFICATIONS:

TYPE	ED 300
INPUT VOLTAGE	AC 230V 50HZ
RESISTIVE LOAD	13 AMP

INSERT BATTERY "AA" SIZE 1.5V

■ TECHNICAL DATA

Voltage limit :	85%~110%U _e (50Hz)	Load capacity :	AC250V 13A (ohmic load cos Ø=1)
Hysteresis :	1s/d (at25)		2.5A (inductive load cos Ø=0.6)
On/off operation :	8on & 8off		1000W (glow lamp load)
Minimum interval:	1 minute	Service life :	Mechanically: 10 ⁷
Power consumption :	3.5VA		Electrically: 5x10 ⁴
Ambient temperature :	-10 ~ 55	Display ;	LCD
Storage temperature:	-20~70	Weight :	Approx 120g
Dimensions(hxwxd)mm:	122x60x68		

■ OPERATING INSTRUCTION:

1. INSTALL ONE PIECE "AA" 1.5V BATTERY WITH CORRECT POSITIVE/NEGATIVE POLARITY INTO THE BATTERY HOLDER.

2. PUSH BUTTON FUNCTION :

- (1) **CLOCK:** CLOCK INDICATION
- (2) **DAY:** DAY SET
- (3) **HOUR:** HOUR SET
- (4) **MIN:** MINUTE SET
- (5) **PROG:** 8 SET OF PROGRAMMABLE ON/OFF SETTINGS; DISPLAY 1^{ON}, 1^{OFF}.....8^{ON}, 8^{OFF}
- (6) **RST/RCL:** RESET/RECALL
- (7) **ON/AUTO/OFF:** LOCK ON / ON AUTO / AUTO OFF/ LOCK OFF SELECT

3. CLOCK SETTING:

- (1) PRESS "CLOCK" AND "DAY" TOGETHER TILL CORRECT DATE IS SHOWN
- (2) PRESS "CLOCK" AND "HOUR" TOGETHER TILL CORRECT HOUR IS SHOWN
- (3) PRESS "CLOCK" AND "MIN" TOGETHER TILL CORRECT MINUTE IS SHOWN

4. TIMER SETTING:

- (1) PRESS "PROG" (TIMER 1ST ON MODE)
- (2) PRESS "DAY" STOP AT REQUESTED DATE (10 DEFERENT MODE : 1.MO 2.TU 3.WE 4. TH 5. FR 6. SA 7. SU
8. MO TU WE TH FR 9.SA SU 10. MO TU WE TH FR SA SU
DELECTABLE)
- (3) PRESS "HOUR" STOP AT REQUESTED HOUR
- (4) PRESS "MIN" STOP AT REQUESTED MINUTE
- (5) PRESS "PROG" (TIMER 1ST OFF MODE)
- (6) REPEAT (2) -(4)
- (7) REPEAT (1) -(6) TILL TIMER 8TH OFF MODE IS SETTED
- (8) YOUR MAY PRESS "PROG " FOR DOUBLE CHECKING
- (9) PRESS "CLOCK" TO RESUME PRESENT TIME

5. PLUG APPLIANCES TO TIMER'S RECEPTACLES.

6. TURN ON APPLIANCE , TIMER SHOULD AT "ON AUTO" OR "AUTO OFF" MODE.

7. PLUG TIMER TO AC OUTLET TO COMPLETE SETTING.

8. PRESS "ON/AUTO/OFF" LCD POINTS TO "ON" TO "ON AUTO" TO "AUTO OFF" TO "OFF" FOR MANUAL OPERATION .STOP AT "ON AUTO" OR "AUTO OFF" FOR AUTOMATIC OPERATION.

9. FOR CANCEL ENGAGEMENTS , PRESS "RST / RCL " THEN "- :- -" IS DISPLAYED ON LCD TO CONFIRM CANCEL.

MAY PRESS "RST / RCL " AGAIN TO RESUME INITIAL SETTING.

■ NOTE:

THE POWER CONSUMPTION OF CONNECTED ELECTRICAL APPLIANCES, SHALL BE WITHIN .
THE LIMITATION OF FOLLOWING RATED CAPACITY.